




# Olympus 850SW Battery Latch Replacement

This guide will provide step by step instructions on how to replace the battery latch.

Written By: Kathleen



## Step 1 — Battery Latch



- Locate the battery latch on the bottom of the device.


## Step 2



- Unscrew the one screw on the latch.
- Remove the screw.




### Step 3




- Remove the small black plastic piece positioned at the opening side of the battery latch.

### Step 4



- You will now be able to lift and remove the thin metal covering from battery latch.

## Step 5



- Open the latch.

## Step 6



- Locate the screw in the center crease of the opening of the battery latch.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:27:54 AM.